


## INSTALLATION INSTRUCTIONS

### High Clearance A-Arms: for Can-Am Maverick R (2024)

- A Press or Ball Joint tool is required to remove and install Ball Joints.
- Do not discard packaging until product has been successfully installed.
- Kit does not include A-Arm Bushings. User must purchase and install A-Arm Bushings Kit.

Item	Description
A	Driver Upper
B	Passenger Upper
C	Passenger Lower
D	Driver Lower



#### Liability Statement

SuperATV's® products are designed to best fit user's ATV/UTV under stock conditions. Adding, modifying, or fabricating any factory or aftermarket parts will void any warranty provided by SuperATV® and is not recommended. SuperATV's® products could interfere with other aftermarket accessories. If user has aftermarket products on machine, contact SuperATV® to verify that they will work together.

Although SuperATV® has thousands of satisfied customers, user should be aware that installing lift kits, long travel, or suspension kits, tires, etc. will change the ride of machine and may increase maintenance and part wear. Operating any off-road machine while, or after, consuming alcohol and/or drugs increases risk of bodily harm or death. No warranty or representation is made as to this product's ability to protect user from severe injury or death. SuperATV® urges operators and occupants to wear a helmet and appropriate riding gear at all times.

By purchasing and installing SuperATV® products, user agrees that should damages occur, SuperATV® will not be held responsible for loss of time, use, labor fees, replacement parts, or freight charges. SuperATV®, nor any 3rd party, will not be held responsible for any direct, indirect, incidental, special, or consequential damages that result from any product purchased from SuperATV®. The total liability of seller to user for all damages, losses, and causes of action, if any, shall not exceed the total purchase price paid for the product that gave rise to the claim.

SuperATV® will warranty only parts provided by SuperATV®. Any damage or problems with OEM housings, bearings, seals, or other manufacturers' products will not be covered by SuperATV®. SuperATV® parts and products are not warranted if item was not installed properly, misused, or modified.

Installing, adding, modifying, or fabricating any factory or aftermarket product to your ATV/UTV may violate certain local, state, and federal laws. Be advised that laws vary depending on town, city, county, state, etc. Use of certain products on public streets, roads, or highways may be in violation law. The Buyer is solely and exclusively legally and personally responsible for any violation of the law by the installation or use of the product. You must abide by all local, state, and federal laws, including but not limited to vehicle safety, traffic laws, and ordinances. It is your responsibility to know the laws and how they apply to you.

The Buyer is responsible to fully understand the capability and limitations of his/her vehicle according to manufacturer specifications, warnings and instructions and agrees to hold SuperATV® harmless from any damage resulting from failure to adhere to such specifications, warnings and/ or instructions. The Buyer is also responsible to obey all applicable federal, state, and local laws and ordinances when operating his/her vehicle while using this product, and the Buyer agrees to hold SuperATV® harmless from any violation thereof.

#### Need help with your installation?



sales@superatv.com



www.superatv.com



1-855-743-3427



8:00am - 8:00pm EST M-Th  
8:00am - 7:00pm EST Friday  
9:00am - 2:00pm EST Saturday

#### Read instructions and view illustrations before beginning.

Thank You



For Choosing

**SUPERATV**.COM<sup>®</sup>


**Removal:** Keep all components removed from machine.

**stock components must be removed:**

- If applicable, remove Link from Upper (see pg. 4)
- Caliper
- Hub
- Shock
- Tie Rod from Knuckle
- Knuckle
- Upper and Lower Arms
- Brake Line and Stabilizer Link from Lower



**Removal continued**







### **Machines equipped with Smart-Shox:**

- Disconnect Wiring Harnesses from Shocks. Reconnect after installation is complete.
- Separate from Brakelines. Resecure after installation is complete.
- Disconnect Links from A-Arms.

**Lower Springs should be in stock orientations on Shocks. Potential interference may occur if Shocks have been disassembled and not reassembled correctly.**




- Install stock Ball Joints into new Lower.



**Unless noted, driver side installation shown in illustrations.**

- Install Lower and Upper A-Arms (D)(A) to Frame with stock hardware; tighten.



- If applicable, secure Link to Driver Upper (A) with stock hardware; tighten.




- Reinstall Shock to Frame with stock hardware; tighten.





- Secure Shock and Knuckle to Driver Lower (D) with hardware shown; tighten.



- Secure Knuckle to Driver Upper (A) with stock hardware; tighten.



- Secure Sway Bar Link to Driver Lower (D) with stock hardware; tighten.





- Reinstall Hub, Brake, and Tie Rod; tighten.



- Secure Axle; tighten.



- Reinstall Caliper; tighten.



- Repeat steps for passenger side installation.
- Secure Brake Lines to Lower with components shown; tighten.

