



WARRANTY

Should your product require service, please consult with the dealer from which it was purchased or contact a local UTV STEREO dealer directly. Units received without an accompanying return authorization number will not be processed. Please contact your UTV Stereo dealer or contact UTV Stereo directly to obtain a return authorization number. Additionally, you must include a copy of your purchase receipt from an authorized UTV Stereo dealer for consideration of an in-warranty service. Units received without a receipt will be held for 30 days. Allowing us time to contact you and obtain a copy of the receipt. After 30 days, all units will be returned. For more information please visit our website.



**DO NOT SUBMERGE THIS PRODUCT.
THIS WILL VOID YOUR WARRANTY.**



**FAILURE TO FOLLOW INSTALLATION
INSTRUCTIONS COULD VOID
YOUR WARRANTY.**

UTV STEREO and the UTV STEREO logo are registered trademarks.
All other brand names are trademarks or registered trademarks of their respective owners.
These trademark holders are not affiliated with UTV Stereo.
All rights reserved. Designed in USA.

Copyright © 2026 UTV STEREO

Tel. 480-616-2299
Address: 7561 East Baseline Road Mesa, AZ 85209

Designed in USA

utvstereo.com

Model:
UTVS-XPD-PORT-KIT



**POLARIS XPEDITION
10" SUBWOOFER PORT KIT**

**DESIGNED FOR
UTV - POWERSPORTS - MARINE**

480.616.2299  UTVSTEREO.COM



CONTENTS:

- Included Parts List
- Installation Instructions

OWNERS MANUAL
FOR MODEL: UTVS-XPD-PORT-KIT

Designed in USA

utvstereo.com



XPEDITION

10" SUBWOOFER PORT KIT

INCLUDED PARTS LIST



THANK YOU FOR CHOOSING UTV STEREO PRODUCTS

Thank you for choosing UTV Stereo products. Your purchase of this UTV Stereo product for use in your UTV indicates your desire for reliability and performance audio that only comes from UTV Stereo.

UTV Stereo is your premiere audio manufacturer. We offer the highest quality products designed for your SxS. Stay one step ahead when you purchase UTV Stereo products.

To take full advantage of the UTV Stereo Xpedition 10" Subwoofer Port Kit, please read and follow the instructions in this manual.

Designed for high performance audio systems, this enclosure is built rugged to withstand the elements. This Xpedition 10" Subwoofer Port Kit has been designed specifically for use in your Polaris® Xpedition.

INSTALLATION

Professional installation by an authorized UTV STEREO dealer is highly recommended! Otherwise, the performance of your new gear may not be satisfactory. In the event that you decide to do your own installation, please read and follow this manual very carefully. Failure to do so may compromise the integrity of this product or your vehicle, and possibly void this product's warranty.



Model:
UTVS-XPD-PORT-KIT

INSTALLATION INSTRUCTIONS

Scan to watch
the install video



Step 25: Enjoy your newly installed UTV Stereo Xpedition Port Kit!





Model:
UTVS-XPD-PORT-KIT

Scan to watch
the install video



INSTALLATION INSTRUCTIONS



- Step 7:** Flip the enclosure over and remove the screw from the back.
- Step 8:** Remove the 8 screws from the OEM subwoofer.
- Step 9:** Lift the subwoofer from the enclosure and unplug it.
- Step 10:** Remove the 5 screws from the front face of the enclosure.
- Step 11:** Use the included dampening pieces to seal the hole as shown.
- Step 12:** Use the included dampening pieces to seal the hole as shown.



Model:
UTVS-XPD-PORT-KIT

Scan to watch
the install video



INSTALLATION INSTRUCTIONS



- Step 13:** Place the UTV Stereo ported front face onto the OEM enclosure and secure using the OEM screws (from step 10)
- Step 14:** Connect the subwoofer wire harness to the 10" UTV Stereo subwoofer.
- Step 15:** Plug the UTV Stereo subwoofer into the enclosure.
- Step 16:** Place the subwoofer into the enclosure & align with the mounting holes.
- Step 17:** Use the included anti-seize on each of the included bolts and tighten securely.
- Step 18:** Slide the enclosure back into the vehicle.

Scan to watch
the install video



INSTALLATION INSTRUCTIONS



19.



20.



21.



22.



23.



24.

- Step 19:** Use the OEM screws to secure the enclosure to the vehicle.
- Step 20:** Plug the OEM subwoofer cable back into the enclosure.
- Step 21:** Reconnect the light in the lower panel.
- Step 22:** Re-attach the lower panel using the plastic OEM clips.
- Step 23:** Re-attach the 2 OEM screws under the lower panel.
- Step 24:** Refer to the OEM clips removed in Step 1.

Scan to watch
the install video



INSTALLATION INSTRUCTIONS



1.



2.



3.



4.



5.



6.

- Step 1:** Remove the 4 plastic clips on the OEM subwoofer grille.
- Step 2:** Remove the 5 plastic clips on the lower panel area.
- Step 3:** Remove the 2 screws shown here.
- Step 4:** Lower the panel and unplug the light.
- Step 5:** Reach behind the center console and unplug the subwoofer.
- Step 6:** Remove the 5 screws for the subwoofer enclosure and remove from vehicle.