

Model: UTVS-R-ENC-10-FDRIVER UTVS-R-ENC-10-FPASS

DESIGNED FOR UTV - POWERSPORTS - MARINE

480.616.2299 / UTVSTEREO.COM



Included Parts List Installation Instructions

OWNERS MANUAL

FOR MODEL: UTVS-R-ENC-10-FDRIVER UTVS-R-ENC-10-FPASS

Designed in USA



MAVERICK R 10" FRONT SUBWOOFER ENCLOSURE

INCLUDED PARTS LIST



THANK YOU FOR CHOOSING UTV STEREO PRODUCTS

Thank you for choosing UTV Stereo products. Your purchase of this UTV Stereo product for use in your UTV indicates your desire for reliability and performance audio that only comes from UTV Stereo.

UTV Stereo is your premiere audio manufacturer. We offer the highest quality products designed for your SXS. Stay one step ahead when you purchase UTV Stereo products.

To take full advantage of the UTV Stereo Maverick R 10" Front Subwoofer Enclosure, please read and follow the instructions in this manual.

Designed for high performance audio systems, this enclosures is built rugged to withstand the elements. This Maverick R 10" Subwoofer Enclosure has been designed specifically for use in your Can-Am® Maverick R.

INSTALLATION

Professional installation by an authorized UTV STEREO dealer is highly recommended! Otherwise, the performance of your new gear may not be satisfactory. In the event that you decide to do your own installation, please read and follow this manual very carefully. Failure to do so may compromise the integrity of this product or your vehicle, and possibly void this product's warranty.



Model: UTVS-R-ENC-10-FDRIVER UTVS-R-ENC-10-FPASS

INSTALLATION INSTRUCTIONS



- Step 1: Slide seat forward and remove both bolts from floor.
- Step 2: Remove bolts for harness lock mechanism.
- Step 3: Remove bolts from seat mount on both sides.
- Step 4: Lift seat to get the black seat belt plug and unplug it (Only on driver side).
- Step 5: Remove seat from car.
- Step 6: Run your sub wire through the rubber grommet (Use glass cleaner ube it).
- Step 7: Make the connections to your subwoofer. (May vary depending on stage kit).
- Step 8: Place the subwoofer into the enclosure and use the 8 hex socket screws to
- secure it (Use anti sieze and do NOT tighten completely until all screws are in place).
- Step 9: Remove the two screws located in floorboard of the vehicle.
- Step 10: Set the enclosure in the vehicle and plug in the sub to the wire harness.
- **Step 11**: Secure the enclosure using the long bolts with rubber washer on the rear (Use anti-sieze and do NOT completely tighten any screws until ALL are in place)
- Step 12: Secure the front by using the two smaller screws. (Use anti sieze)

Repeat steps 1-12 for other side.



WARRANTY

Should your product require service, please consult with the dealer from which it was purchased or contact a local UTV STEREO dealer directly. Units received without an accompanying return authorization number will not be processed. Please contact your UTV Stereo dealer or contact UTV Stereo directly to obtain a return authorization number. Additionally, you must include a copy of your purchase receipt from an authorized UTV Stereo dealer for consideration of an in-warranty service. Units received without a receipt will be held for 30 days. Allowing us time to contact you and obtain a copy of the receipt. After 30 days, all units will be returned. For more information please visit our website.



DO NOT SUBMERGE THIS PRODUCT.
THIS WILL VOID YOUR WARRANTY.



FAILURE TO FOLLOW INSTALLATION INSTRUCTIONS COULD VOID YOUR WARRANTY.

UTV STEREO and the UTV STEREO logo are registered trademarks. All other brand names are trademarks or registered trademarks of their respective owners. These trademark holders are not affiliated with UTV Stereo. All rights reserved. Designed in USA.

Copyright[©] 2024 UTV STEREO

Tel. 480-616-2299 Address: 7561 East Baseline Road Mesa, AZ 85209

Designed in USA utvstereo.com